

SWING-ARM TIRE CHANGER



SWING-ARM

The mounting arm swings to the side so that the machine can be installed in a space-saving way directly near a wall.



ON-FLOOR BEAD BREAKER (PEDAL-OPERATED)

Traditional side-shovel bead breaker with ergonomic pedal-control positioned away from the shovel; the fastest solution for standard, soft sidewall, and high-aspect tires.



PNEUMATIC BEAD ASSIST

Our three-piece Pneumatic Bead Assist features a top roller, pressing foot, and lifting disk, to make it simple for a single technician to mount and demount low-profile and high-performance tires.



ADJUSTABLE CLAMPING JAWS

Self-centering nylon-covered clamping jaws protect the wheel and provide a secure grip.



SYSTEM III-E



COLUMN-INTEGRATED AIR TANK

Unobtrusive, vertical design, columnintegrated air tank helps conserve valuable shop space with a large volume for increased blasting capabilities.

TECHNICAL SPECIFICATIONS

| Max Rim Diameter | 24" 61cm |
|-----------------------|-----------------------------|
| Max Tire Width | 15" 38cm |
| Max Wheel Diameter | 50" 127cm |
| Power Supply | 115V 1ph 60Hz 12A |
| Air Pressure Required | 116-174 PSI 8-12 bar |
| Dimensions HxWxD | 82"x49"x52" 208x124x132cm |

STANDARD ACCESSORIES

- · Wave Plus Tire Lever
- Bead Breaker Blade Protector
- · Lube Bucket & Bottle
- Lube Brush
- Protective Insert for Mount/Demount Head
- Plastic Jaw Protector







