

# **SWING-ARM** TYRE CHANGER



#### **SWING-ARM**

The mounting arm swings to the side so that the machine can be installed in a space-saving way directly near a wall.



## ON-FLOOR BEAD BREAKER (PEDAL-OPERATED)

Traditional side-shovel bead breaker with ergonomic pedal-control positioned away from the shovel; the fastest solution for standard, soft sidewall, and high-aspect tyres



### **TOP-SIDE BEAD SEATER**

This ergonomic hand-held nozzle injects a high-speed blast of air into the tyre to raise the bead and seal the tyre to the rim.



# T1300B



## **TECHNICAL SPECIFICATIONS**

Max Rim Diameter	22"   56cm
Max Tyre Width	13"   33cm
Max Wheel Diameter	39"   100cm
Power Supply	400V 3ph 50Hz 5,5A
Air Pressure Required	116-174 PSI   8-12 bar
Dimensions HxWxD	50"x68"x45"   125x173x115cm

### STANDARD ACCESSORIES

- 1 kg Lube Bucket Holder
- Tyre Lever Wave Plus
- · Plastic Protectors for Mounting Head

### **OPTIONAL ACCESSORIES**

- Lube Brush
- Plastic Rim Protector
- Plastic Tyre Protector
- Smart Bead Spacer
- Bead Clamp
- · Plastic Protector for Bead Breaker Blade
- · Bead Breaker Blade for Off-**Road Wheels**
- · Roller Board



FIND A DISTRIBUTOR









