

TILT-TOWERTIRE CHANGER



TILT-TOWER

The pneumatic Tilt-Tower post provides maximum clearance for installing the tire on the turntable.



PROspeed™

The innovative self-adjusting technology provides the optimum torque and maximizes the rotation speed for safe, efficient operation.



ON-FLOOR BEAD BREAKER (PEDAL-OPERATED)

Traditional side-shovel bead breaker with ergonomic pedal-control positioned away from the shovel; the fastest solution for standard, soft sidewall, and high-aspect tires.



ADJUSTABLE CLAMPING JAWS

Self-centering nylon-covered clamping jaws protect the wheel and provide a secure grip.

T5540T

TOOL BOX WITH INTEGRATED AIR PRESSURE GAUGE

The tool box provides a fixed storage area with four convenient shelves for tools, valves, and accessories, with an integrated air pressure gauge.

PNEUMATIC VERTICAL ARM

Fast and ergonomic, the pneumatic vertical arm facilitates positioning of the mounting head on all wheels.

TABLETOP BEAD SEATER

A direct burst of compressed air comes through the clamping jaws to facilitate bead seating.



TECHNICAL SPECIFICATIONS

Max Rim Diameter	24" 61cm
Max Tire Width	15" 38cm
Max Wheel Diameter	39" 100cm
Power Supply	230V 1ph 50-60Hz 16A
Air Pressure Required	116-174 PSI 8-12 bar
Dimensions HxWxD	64"x66"x49" 162x169x126cm

STANDARD ACCESSORIES

- 5 kg Lube Bucket HolderLube Brush
- · Bead Breaker Blade Protector
- Jaw Protectors Front & Rear
- Plastic Protectors for Mounting Head
- · Rim Protection and String
- · Wave Lever PLUS
- · Wave Lever PLUS Protector

OPTIONAL ACCESSORIES

- Quick Exchange Device with Mounting Head
- Bead Breaker Blade for Off-Road Wheels
- Wheel Lift
- MH Tractor Kit
- 4-inch Jaw Adaptors for Centre Type Sliding Jaws
- Light Truck Adaptor for Centre Type Sliding Jaws
- 26-inch Motorcycle Adaptor Kit for Centre Type Sliding Jaws
- Motorcycle Mounting Head
- Motorcycle Bead Breaker Blade
- · Slip-on Shoe
- Extension Bead Breaker Arm for Extra-Large Wheels
- Roller Board



FIND A DISTRIBUTOR



