

# **TILT-TOWER**TIRE CHANGER



#### **TILT-TOWER**

The pneumatic Tilt-Tower post provides maximum clearance for installing the tire on the turntable.



## ON-FLOOR BEAD BREAKER (PEDAL-OPERATED)

Traditional side-shovel bead breaker with ergonomic pedal-control positioned away from the shovel; the fastest solution for standard, soft sidewall, and high-aspect tires.



#### PNEUMATIC BEAD ASSIST

Our three-piece Pneumatic Bead Assist features a top roller, pressing foot, and lifting disk, to make it simple for a single technician to mount and demount low-profile and high-performance tires.



#### **ADJUSTABLE CLAMPING JAWS**

Self-centering nylon-covered clamping jaws protect the wheel and provide a secure grip.

## **SYSTEM V**



Fast and ergonomic, the pneumatic vertical arm facilitates positioning of the mounting head on all wheels.

### TOOL BOX WITH INTEGRATED AIR PRESSURE GAUGE

The tool box provides a fixed storage area with four convenient shelves for tools, valves, and accessories, with an integrated air pressure gauge.



A direct burst of compressed air comes through the clamping jaws to facilitate bead seating.



Max Rim Diameter	26"   66cm
Max Tire Width	17"   43cm
Max Wheel Diameter	47"   119cm
Power Supply	230V 1ph 50-60Hz 16A
Air Pressure Required	116-174 PSI   8-12 bar
Dimensions HxWxD	58"x65"x90"   147x165x229cm

CHERRICALIUM

#### STANDARD ACCESSORIES

- · Wave Plus Tire Lever
- · Plastic Rim Protector
- Bead Breaker Blade Protector
- · Lube Bucket
- Lube Brush
- Offset Mount/Demount Head Kit
- Protective Insert for Mount/Demount Head





