SYSTEM III-E UNCOMPLICATED SYSTEM UNDENIABLE ADVANTAGE

If you regularly work on larger wheels and tires that are common on today's modern performance cars and SUVs, the John Bean[®] System III-E swing-arm tire changer is a fantastic addition to your shop.

The System III-E allows you to work on tires up to 15 inches in width and 42 inches in diameter, which covers a range of vehicles.

An ergonomic, pedal-operated on-floor bead breaker allows technicians to work with tires all the way up to 15 inches wide with ease.

Powered by twin cylinders, the nyloncovered clamping jaws make quick work of holding large wheels in place on the turntable while minimizing the chance of damage.

Big features packed in a compact footprint the System III-E is the workhorse you need.



SWING-ARM TIRE CHANGER



SWING-ARM

The mounting arm swings to the side so that the machine can be installed in a space-saving way directly near a wall.



ON-FLOOR BEAD BREAKER (PEDAL-OPERATED)

Traditional side-shovel bead breaker with ergonomic pedal-control positioned away from the shovel; the fastest solution for standard, soft sidewall, and high-aspect tires.



PNEUMATIC BEAD ASSIST

Our three-piece Pneumatic Bead Assist features a top roller, pressing foot, and lifting disk, to make it simple for a single technician to mount and demount low-profile and high-performance tires.



ADJUSTABLE CLAMPING JAWS

Self-centering nylon-covered clamping jaws protect the wheel and provide a secure grip.

WHEN GOOD ENOUGH ISN'T ENOUGH, JB.



SYSTEM III-E



24" | 61cm

15" | 38cm

50" | 127cm

115V 1ph 60Hz 12A

116-174 PSI | 8-12 bar

82"x49"x52" | 208x124x132cm

COLUMN-INTEGRATED AIR TANK

Unobtrusive, vertical design, columnintegrated air tank helps conserve valuable shop space with a large volume for increased blasting capabilities.

TABLETOP BEAD SEATER

TECHNICAL SPECIFICATIONS

Max Rim Diameter

Max Wheel Diameter

Air Pressure Required

Dimensions HxWxD

Max Tire Width

Power Supply

A direct burst of compressed air comes through the clamping jaws to facilitate bead seating.

STANDARD ACCESSORIES

- · Wave Plus Tire Lever
- Bead Breaker Blade Protector
- · Lube Bucket & Bottle
- Lube Brush
- · Protective Insert for Mount/Demount Head
- · Plastic Jaw Protector



800.362.4618



