

# **SWING-ARM** TIRE CHANGER



#### **SWING-ARM**

The mounting arm swings to the side so that the machine can be installed in a space-saving way directly near a wall.



### ON-FLOOR BEAD BREAKER (PEDAL-OPERATED)

Traditional side-shovel bead breaker with ergonomic pedal-control positioned away from the shovel; the fastest solution for standard, soft sidewall, and high-aspect tires.



#### PNEUMATIC BEAD ASSIST

Our three-piece Pneumatic Bead Assist features a top roller, pressing foot, and lifting disk, to make it simple for a single technician to mount and demount low-profile and high-performance tires.



#### ADJUSTABLE CLAMPING JAWS

Self-centering nylon-covered clamping jaws protect the wheel and provide a secure grip.



## **SYSTEM III-E**



#### COLUMN-INTEGRATED AIR TANK

Unobtrusive, vertical design, columnintegrated air tank helps conserve valuable shop space with a large volume for increased blasting capabilities.

#### **TECHNICAL SPECIFICATIONS**

Max Rim Diameter	24"   61cm
Max Tire Width	15"   38cm
Max Wheel Diameter	50"   127cm
Power Supply	115V 1ph 60Hz 12A
Air Pressure Required	116-174 PSI   8-12 bar
Dimensions HxWxD	82"x49"x52"   208x124x132cm

#### STANDARD ACCESSORIES

- · Wave Plus Tire Lever
- Bead Breaker Blade Protector
- · Lube Bucket & Bottle
- · Lube Brush
- Protective Insert for Mount/Demount Head
- Plastic Jaw Protector



**Applies only to Canadian models:** This product conforms to UL STD 201 and is Certified to CSA STD C22.2 #68







